

## TECHNICAL INFORMATION

FOR PROFESSIONAL USE ONLY

### addsTROTON DUST MASK



#### PRODUCT DESCRIPTION

Dust mask designed to protect against solid and liquid aerosols. Category: FFP2: protection against non-toxic and low-to-average toxicity solid and liquid aerosols (e.g. oil-mists) in concentrations up to 12 x MAC/OEL/TLV or 10 x APF. Single use product shall not be used for more than one shift.

Adjustable nosepiece and inner foam provide a custom seal. Conforms to EN149:2001 + A1:2009 standards. Product is available with filter and without filter.

MAC = Maximum Admissible Concentration  
OEL = Occupational Exposure Limit  
TLV = Threshold Limit Value  
APF = Assigned Protection Factor

**FITTING INSTRUCTIONS**

1. Hold the mask with one hand with the noseclip at your fingertips and both elastic headbands hanging free.
2. Place the mask against your face holding it with one hand with its lower part on your chin, the noseclip on your nose and the elastic straps between your hand and the mask. Pass the lower strap over your head and place it down your ears, on your nape.
3. Hold the mask with one hand on your face with a soft and firm pressure and with the other hand, fit the upper strap over your ears.
4. Using both hands at once adjust the whole extension of the noseclip to your nose's shape, place the elastic straps in a good position to get a proper face adjustment and, finally, make sure that all the edges of the mask are in direct contact with your face.
5. Fit test. It helps to verify if the mask is properly fitted. For that, cup both hands over the mask and in case of mask with filter make rapid inspiration, and in case of mask without filter exhale vigorously. If air leaks through the edges, you should modify the position of the mask on your face, adjust again the noseclip and/or modify the tension or position of the elastic straps. Repeat this proceeding until no leakage is detected.

**WARNING !**

- Failure to follow all instructions and limitations on the use of this product could reduce the effectiveness of respirator and result in sickness or death.
- A properly selected respirator is essential to protect your health. Before using this respirator, consult an Industrial Hygienist or Occupational Safety Professional to determine the suitability for your intended use.
- This product does not supply oxygen. Use only in adequately ventilated areas containing sufficient oxygen to support life. Do not use this respirator when oxygen concentration is less than 19%.
- Do not use when concentrations of contaminants are immediately dangerous to health or life.
- Do not use in explosive atmospheres.
- Leave work area immediately and return to fresh air if (a) breathing becomes difficult, or (b) dizziness or other distress occurs.
- Facial hairs or beards and certain facial characteristics may reduce the effectiveness of this respirator.
- Never alter or modify this respirator in any way.
- Only for single use. No maintenance necessary. Discard the used respirator after single use.
- Keep respirators in the display box away from direct sunlight until use.